

Full-field characterisation of oxide-oxide ceramic-matrix composites using X-ray computed micro-tomography and digital volume correlation under load at high temperatures

J.P. Forna-Kreutzer, J. Ell, H. Barnard, T.
Pirzada, R. O. Ritchie, D. Liu

BCI Showcase

13 April 2021

Outline


- Introduction
 - Oxide Ceramic-Matrix Composites
 - Aim
- Experimental Procedure
 - Materials
 - Methods
- Results
 - Mechanical Testing
 - Digital Volume Correlation
- Conclusions

Introduction

- Oxide (Al_2O_3 -based) CMCs:
 - + Improved oxidation stability over SiC CMCs → better lifetimes;
 - Reduced mechanical performance: strength and creep.
- Aim:
 - Test the suitability of in situ X-ray computed microtomography (XCT) coupled with digital volume correlation (DVC) for the full-field characterization of oxide/oxide CMCs
 - Investigate the relationship between microstructure, local 3D strain and damage mechanisms a novel technique: DVC

Experimental Procedure

- Materials:
 - Woven Nextel™ 720/Alumina (720/A) – porous matrix
 - **Material A:** sintered at 1200°C
 - **Material B:** sintered above 1250°C
- Methods:
 - 3-point bending (3-PB) with *in situ* XCT, ALS, USA (Prof. Robert Ritchie)
 - Fixed dimensions: 3x4x25mm (21mm support span)
 - Room temperature (RT) and 1050°C (HT) in Air
 - Avizo XDigitalVolumeCorrelation – Global DVC





3-PB μ XCT cell during high temperature test



Results: 3-point bending

Material	Test Temperature	Flexural Strength ¹ (MPa)
A	RT	58.8 ± 1.2
A	1050°C	55.3 ± 4.5
B	RT	93.7 ± 7.7
B	1050°C	103.8 ± 11.1


- Higher overall strength for material **B**
- More pronounced load drops at 1050°C for material **B**
- A more consistent behavior going from RT to 1050°C for material **A**



Results: Microstructure




- **Type I** – Interfacial cracks which leads to high curvatures and porosity
- **Type II** – Inclined intra-tow cracks
- **Type III** – Opening of matrix shrinkage cracks
- **cracks** – Extent and distribution of matrix shrinkage cracks varies within single specimens and across specimens
- **Secondary** – Microcracking and ligament bridging






Results: In situ DVC observations

Banding of the shear components

AA-050°C



B-1050°C



Conclusions

1. The sintering temperature appears to have a significant effect on the mechanical properties of the tested material systems
2. Three primary types of cracks were identified
 - Type I: interfacial cracks
 - Type II: inclined cracking inside the 90° fibre tows
 - Type III: the opening of existing matrix shrinkage cracks
3. The applicability of DVC to oxide-oxide CMCs was demonstrated
4. Areas of maximum principal strain were good predictors for eventual fracture locations
5. High local shear strains with abrupt positive to negative transitions were observed – attributed to the different bonding strength between the 0/90° fibres and the matrix

Future Work: Continued XCT/DVC testing of more advanced CMC systems;

Residual stress analyses using fluorescence microspectroscopy; nano-indentation.

Acknowledgements

- The authors would like to thank the Engineering and Physical Sciences Research Council (EPSRC) for the funding provided for the present study (Grant Refs: EP/L016028/1 and EP/T000368/1). The authors also acknowledge the use of the X-ray synchrotron micro-tomography beamline (8.3.2) at the Lawrence Berkeley National Laboratory's Advanced Light Source, which is supported by the U.S. Department of Energy, Office of Science, Office of Basic Energy Sciences of the U.S. Department of Energy under contract no. DE-AC02-05CH11231. D.L. and R.O.R. would like to thank Dr. Dula Parkinson for help with the synchrotron tomography experiments.

CDT_End

Email.Address@bristol.ac.uk